


PAPER FILTER (PFA240~500)



No	Name	Q	Material	No	Name	Q	Material
1	Tank	1		8	Support wheel	8	
1A	Drain	1		9	Set Screw	3	M16
2	Supply Pump	1	1HP*180L	10	Nut	6	M16
3	Frame	1		11	Inlet	1	
4	Motor	1	5IK60GX	12	Safe Cover		
4A	Mid Gear Head	1	5GX10XK	13	Paper Box	1	
4B	Gear Head	1	5GX100KB	14	Paper Box Cover	1	
5	Drive Shaft	1		15	Electrical Box	1	
5A	Driven Shaft	1		16	Limited Switch	1	TZ6104
6	Conveyor Chain Set	1		17	Float Switch	1	
7	Sprocket	4	#530*18T				

Remark in Usage:

- 1: Before power on, you must inspect if the voltage and the phase as correct as indicative instruction. If they mismatch, it will make damages.
- 2: If motor direction (Arrow direction) is incorrect, please exchange two power cards arbitrarily.
- 3: Pull up the float ball slightly before paper goes under the float ball.
- 4: Paper length must exceed filter frame's one; it is better to pull into the chip collector.
- 5: Keep an eye on if it is too much sludge in chip collector in order to avoid paper winding into frame.

